
## **Add Drawing**

If there are imported drawings in the current project, and you want to import another drawing to the current area as the reference, you can use this function.

- 1. Click **Insert Drawing**, and then select the drawing that you want to insert.
- 2. Click **OK**, enter the scale, and then the drawing will be inserted to the current drawing area.





## Note

1. You can only insert one drawing at one time by using Insert Drawing.

## **Cubicost- TAS C**

- 2. No name info of the inserted drawing can be generated in the Drawing Manager.
- 3. In the Drawing Manager, if you delete the name of the current drawing, the inserted drawing will also be deleted simultaneously.