# Scale Drawing

In actual project drawings, if the floor plans for all floors are drawn in one drawing, you can use this function to make it easy to identify elements in each floor.

1. Click **Split Drawing**, and then drag-select the drawing that you want to split.

2. Right-click to confirm, and then in the **Please input drawing name** window, enter the name of the split drawing.

Please input drawing name ×

Drawing Name: level lower ground

☐ Add Text to Drawing Name

Note: Input the name manually or click to pick it from the drawing.

OK   Cancel

3. Click **OK**, and then in the **Drawing Manager**, the name of the split drawing

will be generated.

2	⊟ 00-PLAN 2017 05 22 - ...	1:1	17/10/15
	00-PLAN 2017 05 22...	1:1	17/10/15
	level lower ground	1:1	17/10/15

Note

1. Double-click the split drawing to show it in the drawing area.