
Modify Name

In actual situations, you may draw elements incorrectly, for example, mistake Col-2 as Col-1. Design changes occur at the construction stage. For example, the entity C-1 at a specific location is changed to C-3, and its attribute info is changed accordingly.

1. Click **Modify Name**, select the entity that you want to modify, and then right-click to confirm.



2. In the **Modify Element Entity Name** window, the entity is selected by default. In the **Target Element** area, select the check box for the element that you want to replace, for example, C-2.

Cubicost- TAS C

3. Click OK, and then the select C-1 is changed to C-2.

Note

Selecting the **Reserve private attributes** check box helps you to save the attribute values in black font of C-1. Such as Top Elevation.