

Partial 3D

To view the 3D status of a specific entity wholly or partially, you can use this function.

1. Click Partial 3D, and then drag a box to select the entities you want to view.



2. In the drawing area, you can only view the 3D status of selected entities.



Note

To exit the 3D view, Click **Partial 3D** again.