


3D Measure

With TAS C, you cannot get the quantities of special-shaped entities. To obtain their quantities, you can use this function to measure the areas and lengths of each face.

1. In the View Expression window, click **3D Measure** to enter the measure view.
2. Select Pick Line or **Pick Area**, and then specify the line or area that you want to measure on entities.
3. At the bottom of the window, the selected length and area are displayed.



Note

Cubicost- TAS C

If you select multiple segments, the measurement result will be added up automatically.