

2D/3D

When drawing models, if you want to switch between 2D view and 3D view for easy check, you can use this function.

To change from 2D status to 3D status, click **2D/3D**. (If the current project is in 3D view, you can click it to auto switch to 2D view.)

