

## Filter Associated Item

To facilitate check and adjustments, after associating quantities with BQ items, if you want to view the BQ items which the quantities have been associated with, you can use this function.

1. Click **View Quantity by Category**.
2. Select the quantity cell you want to filter.
3. Slide to turn on the switch for Filter Associated Item.
4. Click **Filter Associated Item**.
5. The BQ items corresponding to the selected quantity will be filtered out.

# Cubicost- TAS C

H h I N

Heading Sub Heading Item Note

View Quantity by Category

Reversely-Check Quantity

Check BQ

Column Display

Expand All

Collapse All

Hide Detail

Delete

Export to Excel

New

Operate

	Item	Description	Type	Unit	Calculated Qty	Rate	Amount	Expressi
10	A	Sides thick of curved wall; exceeding 300mm	Item	M2	0.000			
11	B	Wall thickness240	Item	M	175.838			V
12		Element Type:Wall;			175.838			V

View Quantity by Category
— □ ×

Column

**Wall**

Beam

Coupling Beam

Component

Set Classification and Quantity
Show Association Status

Classification Condition						Quantity		
Floor	Material	Concrete Grade	Entity Type	Thickness	Name	Volume(m3)	Area of Formwork(m2)	Length of Formwork Edge and E in Stages(0.1-)(m)
1			Curved	240	RCwall-240	7.777	77.117	
2	Ground Floor	In-situ Concrete	Vertical	120	RCwall-120	8.925	135.740	
3		240		RCwall-240	159.137	1360.075		
4	Total					175.838	1572.932	

Show Subtotal
 Filter Associated Item
 Reversely-Check Model

29		Sides of column	Item	M2	0.000			
30	T	Sides and soffit of beam	Item	M2	0.000			
31	U	Sides of plain wall	Item	M2	0.000			
32		To Collection (RM)	Note					
33			Note					